


# Crimp Tool 1526955-1

#### **PROPER USE GUIDELINES**

Cumulative Trauma Disorders can result from the prolonged use of manually powered hand tools. Hand tools are intended for occasional use and low volume applications. A wide selection of powered application equipment for extended-use, production operations is available.



ADAPTER			WIRE			
CRIMP TOOL 1526955-1		AMERICAN ELECTRICAL	Heavy-Duty Lug Terminal		AMP Power Series 50 and 75 Contacts	
PART NUMBER	MARKING	TERMINAL (AET) CRIMP TOOL T-406	SIZE (AWG)	STRIP LENGTH (mm [in.])	SIZE (AWG)	STRIP LENGTH (mm [in.])
1527508-1	А	5992	6	11.11 [ <sup>7</sup> / <sub>16</sub> ]	6, 8, 10, 12	12.06–13.33 [.475–.525]
			4	12.70 [ <sup>1</sup> / <sub>2</sub> ]		
1527507-1	В	5991	1/0	17.46 [ <sup>11</sup> / <sub>16</sub> ]	_	_
			2/0	17.46 [ <sup>11</sup> / <sub>16</sub> ]		
1527505-1	С	5989	2	14.29 [ <sup>9</sup> / <sub>16</sub> ]		
			1	15.87 [ <sup>5</sup> / <sub>8</sub> ]		
No Adapter	_	No Adapter	3/0	19.05 [ <sup>3</sup> / <sub>4</sub> ]		
			4/0	20.64 [ <sup>13</sup> / <sub>16</sub> ]		

Figure 1

TOOLING ASSISTANCE CENTER 1-800-722-1111

PRODUCT INFORMATION 1-800-522-6752

## 1. INTRODUCTION

Crimp Tool 1526955-1 is used to crimp heavy-duty lug terminals (reference part number 1526000-2) and AMP Power Series 50 and 75 contacts (reference part number 647877-1) onto stranded copper wire sizes 6 through 4/0 AWG. See Figure 1.

This instruction sheet has been updated to meet corporate requirements.



Dimensions in this instruction sheet are in millimeters [with inches in brackets]. Figures are not drawn to scale.

### 2. DESCRIPTION

The tool consists of jaws, handles, and three adapters. Each adapter is marked with an alphabetic letter to correspond with the wire size being used. See Figure 1.


# 3. CRIMPING PROCEDURE

1. Strip the wire to the dimension given in Figure 1.

- 2. Install the applicable adapter onto the jaw.
- 3. Fully insert the wire into the wire barrel.
- 4. Center the wire barrel with the wire in the adapter. For the lug terminal, make sure that the pad side of the wire barrel faces the tool indenter.
- 5. Completely close the tool handles. Open the handles, and remove the product.
- 6. Inspect the product for a quality crimp. Refer to Figure 2.



For detailed inspection requirements for the AMP Power Series contacts, refer to Application Specification 114-13071.



<sup>©2007</sup> Tyco Electronics Corporation, Harrisburg, PA All International Rights Reserved

TE logo and Tyco Electronics are trademarks.

<sup>\*</sup>Trademark. Other products, logos, and company names used are the property of their respective owners.