

Figure 1

## 1. INTRODUCTION

This instruction sheet covers application, inspection and maintenance procedures for DYNA-CRIMP Crimping Head 69051 shown in Figure 1. The crimping head uses interchangeable crimping dies used to crimp products listed in Figure 2. This instruction sheet provides general information for the insertion of dies and the crimping procedure. Always refer to the instructions packaged with specific die sets for specific crimping instructions.

Products Crimped	Corresponding Die Set Instruction Sheet
AMPLI-BOND* Terminals, Wire Sizes 8-2 AWG	<a href="#">408-1758</a>
PLASTI-GRIP* Terminals, Wire Sizes 8-2 AWG	<a href="#">408-1729</a> and <a href="#">408-1758</a>
Pre-Insulated AMPPOWER* Terminals, Wire Size 2 AWG	<a href="#">408-1758</a>
TERMINYL* Terminals and Splices, Wire Sizes 8-2 AWG	<a href="#">408-1729</a>
Pre-Insulated AMPPOWER* Terminals, Wire Sizes 4-2 AWG	<a href="#">408-1729</a>

Figure 2

This crimping head is designed for two DYNA-CRIMP tools: either Hydraulic Hand Pump 314979-1 described in Customer Manual [409-5860](#); or Hydraulic Power Unit 69120-[ ] described in Customer Manual [409-1950](#).

**Warning:** To avoid personal injury and potential damage to the crimp head, TE Connectivity (TE) requires the crimp head to operate at 8,000 to 8,400 PSI [552 to 579 bar]. TE recommends using 8,200 PSI [565 bar] TE Hydraulic Pumps as other manufacturers' pumps may apply insufficient pressure (resulting in an inadequate crimp) or excessive pressure (resulting in failure of the head). Additionally, the TE pump must be used to maintain CE certification; if using other manufacturers' pumps, the user is responsible for self-certification.

Read these instructions and other applicable references carefully before proceeding.

**NOTE**

*Dimensions in this instruction sheet are in millimeters [with inches in brackets]. Illustrations and figures are for reference only and are not drawn to scale.*

Reasons for reissue of this Instruction Sheet are provided in Section 8; REVISION SUMMARY

## 2. DESCRIPTION

Main components of the crimping head are: a yoke which houses the stationary die and retains the terminal assembly for crimping, a removable latch pin which allows pivoting of the yoke on the pivot pin (typically required for splice terminations), a cylinder which contains the head's hydraulic chamber, a piston (ram) which holds and controls the moving die, and a quick connect/disconnect coupler (cylinder half) which mates with the coupler on hose or handle control to release or supply pressure.

**DANGER**

*To avoid injury when using DYNA-CRIMP equipment, observe the following precautions:*

- *DO NOT modify the crimping equipment in any way.*
- *USE ONLY dies, terminals, and wire specified for the head.*
- *DO NOT perform repairs other than those specified in the instructional material supplied with the equipment.*

## 3. CRIMPING HEAD INSTALLATION

Each crimping head is shipped with a coating of lubricating oil to prevent rust and corrosion. Wipe the oil off before installing the crimping head on the power unit. Note that the crimping head is shipped without oil inside the cylinder. To install crimping head, proceed as follows:

**DANGER**

*Verify that the hydraulic pressure to hose or handle control is released and that power supply is disconnected from electric power unit, if applicable.*

**NOTE**

*If a coupling component for the hose assembly is packaged inside the quick connect/disconnect coupler on the head, it is to be used to replace the coupling on a hose assembly not equipped with a quick connect/disconnect coupler.*

1. Thoroughly clean coupling area of handle control or hose assembly and crimping head (see Figure 1).
2. Remove protective dust caps from both quick connect/disconnect couplers.
3. Hold hose or handle control in vertical position to prevent oil spillage. Attach hose or handle control to coupling section on head. **THREAD PROPERLY AND TIGHTEN SECURELY.**

**CAUTION**

*Oil flow must be unobstructed between power unit and crimping head. Verify that all couplers are fully mated and tightened.*

**NOTE**

*If crimping head must be removed after being in production, pressure must be released in the hydraulic system before head is removed.*

- *If using Hydraulic Power Unit 69120-[ ], disconnect power unit from power supply.*
- *If using Hydraulic Hand Pump 314979-1, depress pressure release lever.*

## 4. DIE INSERTION AND REMOVAL (FIGURE 3)

**DANGER**

*Use extreme care when operating power unit. DO NOT inadvertently actuate the tool when installing or changing dies. Personal injury could result.*

#### 4.1. Die Insertion



**NOTE**

Before dies are inserted, loosen the socket head cap screws that hold the insulation crimping section of the dies in place. If screws are not loosened, the dies may not fit into the head of the tool because of close clearance. The insulation crimp adjustment must be made in accordance with the instruction sheet packaged with the dies.

1. Remove latch pin and open yoke on crimping head.
2. Loosen setscrew in yoke.
3. Insert stationary die (die with large shank) into yoke as shown in Figure 3. Tighten the setscrew.




Figure 3

4. Activate tool to advance ram until setscrew is visible.
5. Loosen set screw in ram and insert moving die (die with small shank) into ram as shown in Figure 3. Tighten set screw.



**NOTE**

Be sure moving die is properly oriented with stationary die.

6. Return ram to the “DOWN” position.
7. Close yoke and insert latch pin.



**CAUTION**

Ensure latch pin is fully inserted or damage may occur to the yoke, dies, or latch pin.

#### 4.2. Die Removal

1. Remove latch pin and open yoke on crimping head.
2. Loosen set screw in yoke and remove stationary die.
3. Raise ram to “full up” position. Loosen set screw and remove moving die.



**NOTE**

Latch Pin Kit 69709 is available as an accessory item. The latch pin is attached to the pivot pin by a chain to avoid misplacing the latch pin.

## 5. CRIMPING PROCEDURE

The following crimping procedure provides general information. Refer to instructions packaged with individual die sets for specific products, wire sizes, strip dimensions, positioning of terminals and splices in the dies, and crimping procedures.



### **DANGER**

*To prevent personal injury when operating the power unit, exercise caution while holding terminals, splices or wire near crimping area.*



### **CAUTION**

*Never operate the power unit without having a crimping head attached to the handle control or crimping head coupling.*

1. Insert terminal or splice in the stationary (upper) die in accordance with instructions packaged with the dies. Verify the latch pin is secure before activating the power unit.
2. Slowly advance moving (lower) die with short, quick strokes until terminal or splice is secure.
3. Insert the stripped wire.
4. Cycle tool to complete crimp. Remove crimped terminal or splice.



### **NOTE**

*If the splice or terminal sticks in the die after crimping, apply a rocking action to release it.*

## 6. INSPECTION AND MAINTENANCE



### **DANGER**

*Verify hydraulic pressure is released and power supply is disconnected before following maintenance and inspection procedures, unless otherwise specified in the procedure.*

Each crimping head is assembled and inspected before shipment. TE Connectivity recommends that the crimping head be inspected immediately upon its arrival at the facility of use, and at regularly scheduled intervals, to ensure the head has not been damaged during handling and use. Frequency of inspection depends upon the following: care, amount of use, and handling of the head; type and size of products crimped; degree of operator skill; and environmental conditions.

### 6.1. Cleaning

Remove accumulations of dirt and grease on the crimping head; especially in areas where dies are installed and terminals are crimped. Clean the entire head frequently with a clean, lint-free cloth.

### 6.2. Visual Inspection

Refer to Figure 4 and proceed as follows:

1. With hydraulic pressure released, inspect the assembled head for nicks, scratches, and cracks. Inspect for cracks especially at the corners of the yoke and around the top of the cylinder.
2. Inspect pivot pin holes and latch pin holes for wear. Replace parts, as needed.
3. When the head is disassembled (paragraph 6.4.), inspect metal surfaces for nicks, cracks, scratches or excessive wear, especially where sliding contact occurs.
4. If head shows evidence of galling, cracks, oil leakage, or rough cycling, return the crimping head to TE for repairs. Refer to Section 7, REPLACEMENT PARTS AND REPAIRS.



### **NOTE**

*Once per year, or every 7,500 cycles (whichever comes first), the hydraulic head should be returned to TE for magnetic particle inspection. Additionally, inspect and service the head (as described in Figure 4) every month or 1,000 cycles. Refer to Instruction Sheet [408-9684](#).*




Figure 4

### 6.3. Crimping Head Check-Out Procedure

If the ram fails to return to the “DOWN” position after completion of a crimping cycle, the cause may be in the crimping head. To determine whether the trouble is in the crimping head or not, release pressure in the power unit.

If the ram retracts, the trouble is not in the crimping head.

If ram does NOT retract, refer to Paragraph 6.4.

### 6.4. Crimping Head Disassembly Procedure [Figure 5]



**DANGER**

*Verify that the hydraulic pressure to hose or handle control is released and that power supply is disconnected from electric power unit, if applicable.*



**NOTE**

*Numbers in parentheses refer to Item Numbers in Figure 5.*

1. Remove crimping head from handle control or coupling and place in a vise.  
Use a suitable material to protect the finish on the head.
2. Remove the set screw (Item 7) that secures the head assembly to the cylinder.
3. Turn the head assembly counterclockwise to remove it from the cylinder.
4. Remove the piston (Item 5) and piston return spring (Item 6). Inspect for broken or weak piston return spring (Item 6) and deteriorated or torn piston “O” ring (Item 3), and back-up ring (Item 4).  
Replace with new parts if damaged.
5. Apply a thin film of hydraulic fluid (same type used in power unit reservoir) on the surface of the “O” ring and back-up ring.

6. Install piston and piston return spring (Item 6) in the cylinder.
7. Align keyway on ram with key screw (Item 10a) in the head.  
Screw head into cylinder and tighten by hand.
8. Loosen the head until the set screw hole in cylinder aligns with the hole in head.
9. Install set screw (Item 7) in the side of the cylinder. **Be sure set screw is installed through the cylinder and against the threads of the head.**
10. Attach crimping head to handle control or coupling (refer to Section 3).

## 7. REPLACEMENT PARTS AND REPAIRS


Customer-replaceable parts are listed in Figure 5. A complete inventory should be stocked and controlled to prevent lost time when replacement of parts is necessary. Order parts through your TE Representative or call 1-800-526-5142, or send a facsimile of your purchase order to 1-717-986-7605, or write, or return the entire tool for evaluation and repair, with a written description of the problem to:

CUSTOMER SERVICE (38-35)  
TE CONNECTIVITY CORPORATION  
P.O. BOX 3608  
HARRISBURG, PA 17105-3608

Tools may also be returned for evaluation and repair. For tool repair service, contact a TE Representative at 1-800-526-5136.

## 8. REVISION SUMMARY

- Added Warning (paragraph 1)
- Added NOTE after paragraph 6.2.4. specifying return to TE for magnetic particle inspection



Item Number	Part Number	Description	Quantity Per Head
1	311470-1	Coupler, Quick-Disconnect, Cylinder Half	1
2	---	---	---
3	2-21053-5	"O" Ring, 1.625 OD x 1.375 ID x .125 Width	1
4	1-21107-1	Ring, Back-Up	1
5	48736	Piston	1
6	301703	Spring, Piston Return	1
7	21061-1	Screw, Socket Set (Cone Point) 4-40 UNC x .125 inch Long	1
8	48734-1	Cylinder Body	1
9	4-21012-0	Screw, Socket Set Self-Locking (Flat Point) 8-32 UNC x .250 inch Long	2
10*	305438	Cylinder Head and Yoke Assembly (Normally shipped with the following hardware parts already installed:	1
10a**	7-305927-6	Screw, Key	1
10b**	21025-5	Lock Washer, Internal Tooth	1
10c**	306209-1	Pin, Latch	1
10d**	301744	Pin, Pivot	1
10e**	21045-6	Ring, Retaining	2
10f**	4-21012-0	Screw, Socket Set Self-Locking (Flat Point) 8-32 UNC x .250 inch Long	1

\*The head and yoke components (Item 10) are a machine fit and must be replaced as an assembly. Order PN 305438

\*\*These parts may be replaced by the customer when the head and yoke assembly (Item 10) does not need replacement.

Figure 5