



# SPEED SENSOR PLATFORM

Industry

Automotive

Application

Transmission, Engine, Clutch, Chassis, Brake

**Functions** 

Measuring gear speed, travel and angle position

Technology

Hall (moving magnet)

Features

- Triggered by ferromagnetic gear wheel
- · Current interface with direction detection
- · Sealed connector interface
- Diagnostics ability due to two-wire interface
- IP6K9
- Temperature range: -40° C up to +150°C

## **UNITED STATES**

United States – Harrisburg, a TE Connectivity Company Product Information Center: Phone: +1 800-522-6752 Fax: +1 717-986-7575

## ASIA / PACIFIC

Korea – Seoul, a TE Connectivity Company Phone: +82 2-3415-4500 Fax: +82 2-3486-3810

## **SOUTH AMERICA**

South America, a TE Connectivity Company Phone: +54 11-4733-2015 Fax: +54 11-4733-2083

#### **EUROPE**

Germany – Bensheim, a TE Connectivity Company Product Information Center: Phone: +49 6251-133-1999 Fax: +49 6251-133-1988

## ASIA/PACIFIC

Australia – Sydney, a TE Connectivity Company Product Information Center: Phone: +61 2-9840-8200 Fax: +61 2-9634-6188

#### **AFRICA**

South Africa – Port Elizabeth, a TE Connectivity Company Phone: +27 41-503-4500 Fax: +27 41-581-0440

## People's Republic of China

Hong Kong

Phone: +852 2738-8731 Fax: +852 2735-0243

Shanghai

Phone: +86 21-3398-0000 Fax: +86 21-3398-1999

For further contact information please go to:

www.TE.com/support-center

## te.com/sensorsolutions

Measurement Specialties (MEAS), American Sensor Technologies (AST), TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2016 TE Connectivity Ltd. family of companies All Rights Reserved.

