

WIRELESS VIBRATION SENSOR SELECTION GUIDE WHICH MODEL SERIES DO I NEED?



85X1N WIRELESS BLUETOOTH


VIBRATION SENSOR



89X1N WIRELESS LORAWAN VIBRATION SENSOR



WHAT IS MY APPLICATION?



| WHICH REGION WILL THE SYSTEM BE INSTALLED? | | WHICH REGION WILL THE SYSTEM BE INSTALLED? | | WHICH REGION WILL THE SYSTEM BE INSTALLED? | | WHICH REGION WILL THE SYSTEM BE INSTALLED? | |
|--|---------------------------------------|--|---------------------------------------|--|---------------------------|--|--|
| [| | | | | | | |
| 915 MHz | 868 MHz | 915 MHz | 868 MHz | 915 MHz | 868 MHz | 915 MHz | 868 MHz |
| | | | | | | | |
| THREE-AXIS 8931N-EX-A Loraman (Ex) | THREE-AXIS 8931N-EX-E Loral//AN | THREE-AXIS 8931N-NX-A Loraman | THREE-AXIS 8931N-NX-E Loral//AN | SINGLE-AXIS 8911N-EX-A Loraman Ex | SINGLE-AXIS 8911N-EX-E | SINGLE-AXIS 8911N-NX-A Loral/4N | SINGLE-AXIS 8911N-NX-E Loral//AN |

te.com © 2024 TE Connectivity. All Rights Reserved.

Connect with an Expert