

OPERATING INSTRUCTIONS E16AM REV. 1

Variable Reluctance Speed Sensor

E16AM

Product ID

GREEN LINE

INDUSTRIAL SPEED SENSORS

	Type #	Product #	Drawing #	
	E16AM	385Z-05572	114.451 Rev.0	
General				
Function	core, an inductive c the sensor face cha being induced in the speed of the movin gap, geometry of ta	variable reluctance (VR) spe oil, and a permanent magne inges the magnetic field stre e coil. The frequency of the g target. The amplitude of th rget, magnetic properties of ilso known as passive or ele supply.	et. A ferrous pole wheel ength, resulting in an AC output signal is proportion e signal depends on sp target material, and the	passing voltage onal to the beed, air e electrical
Technical data				
Coil properties	Resistance: 850	north pole towards front fac	e	
Polarity	Upon approach of f	errous metal, the signal pin i	s positive with respect t	to GND.
Signal output	The signal amplitud affected by air gap, linear speed of the 100.00 10.00 10.00 10.00 10.00 10.00 0.10 0.05	Typical output voltage (reference speed 10	d for a load of 100 kOhn al. It is also proportional D m/s, 100 kOhm load)	
Frequency range	Up to 20 kHz, lower limit depending on application			
Housing	M16x1.5, tightening torque: max. 35 Nm			
Connection	Connector mates with straight plug MS3106A-10SL-4S, 2 pins			
Protection	Sensor head: IP68 Connector: IP67			
Insulation	Housing and electro	onics galvanically isolated (T	est: 500 V, 50 Hz for 1	minute)

Insulation	Housing and electronics galvanically isolated (Test: 500 V, 50 Hz for 1 minute)
Pole wheel	Prerequisite: Toothed wheel of a ferrous material (e.g. Steel 1.0036). Optimal performance with Involute gear Tooth width > 10 mm Side offset < 0.2 mm Eccentricity < 0.2 mm

Depending on lowest circumferential speed which has to be detected and on Air gap between sensor and



IN CHARGE OF SPEED

OPERATING INSTRUCTIONS E16AM REV. 1

pole wheel	trigger level. See figure.	
Electromagnetic compatibility (EMC)	Please contact Jaquet for further details.	
Vibration & shock immunity	Jaquet Greenline sensors are approved for rough environments. Please contact Jaquet for further details.	
Operating temperature	-40°C125°C	
Further Information		
Safety	All mechanical installations must be carried out by an expert. General safety requirements have to be met.	
Installation	The sensor has to be aligned to the pole wheel according to the sensor drawing independent of its rotational orientation. Deviations in positioning may affect the performance and decrease the noise immunity of the sensor. During installation, the smallest possible pole wheel to sensor gap should be set. The gap should however be set to prevent the face of the sensor ever touching the pole wheel. A sensor should be mounted with the middle of the face side over the middle of the pole wheel. Dependent upon the wheel width, a certain degree of axial movement is permissible. However, the middle of the sensor must be at minimum in a distance of 3 mm from the edge of the pole wheel under all operating conditions. A solid and vibration free mounting of the sensor is important. Eventual sensor vibration relative to the pole wheel can induce additional output pulses. The sensors are insensitive to oil, grease etc. and can be installed in arduous conditions.	
Maintenance	Product cannot be repaired.	
Transport	Product must be handled with care to prevent damage of the front face.	
Storage	Product must be stored in dry conditions. The storage temperature corresponds to the operation temperature.	
Disposal	Product must be disposed of properly, it must not be disposed as domestic waste.	





OPERATING INSTRUCTIONS E16AM REV. 1

