


te.com



Our model RT8DN communicates rotational position feedback via DeviceNET® to your programmable controller. The heart of this sensor is a precision plastic-hybrid position potentiometer which provides an "absolute" position and does not ever have to be reset to a "home" position after a power loss or planned shutdown.

This innovative sensor from Celesco, designed to meet tough NEMA-4 and IP67 environmental standards, is available in full-stroke measurement ranges of 1/8 to 200 turns.

Output Signal



CLICK HERE > **CONNECT WITH A SPECIALIST**

RT8DN

0-45° TO 0-200 TURNS • DEVICENET®

Industrial Grade Rotational Position Sensor Absolute Rotary Position up to 200 turns Aluminum or Stainless Steel Enclosure Options IP68 / NEMA 6

General

Full Stroke Range 0-0.125 to 0-200 turns **Electrical Interface** CANbus ISO 11898 **Protocol** DeviceNet Version 2.0 **Accuracy** see ordering information Repeatability ± 0.02% full stroke Resolution ± 0.003% full stroke **Enclosure Material Options** powder-painted aluminum or stainless steel

Sensor plastic-hybrid precision potentiometer

Potentiometer Cycle Life see ordering information

Shaft Loading up to 10 lbs. radial and 5 lbs. axial

Starting Torque (25°C) 2.0 in-oz., max. Weight, Aluminum 3 lbs. (6 lbs.) max. (Stainless Steel)

Enclosure

Electrical

Bus Powered Input Voltage **Input Current** 40 mA max.


Address Setting (Node ID) 0...63 set via DIP Switches (default setting:


Baud Rate 125K, 250K or 500K set via DIP Switches **EDS** file available @ http:/celesco.com/downloads

Environmental

Enclosure NEMA 4/4X/6, IP 67/68 -40° to 200°F (-40° to 90°C) **Operating Temperature** Vibration up to 10 g to 2000 Hz maximum

Outline Drawing






mounting holes: for .25 in. shaft option, mounting holes are threaded #10-32 x 0.375 deep 120° apart on a 2.00 inch dia. BC

for 6mm shaft option, mounting holes are threaded M6 x 9 mm deep 120° apart on a 50,8 mm dia. BC

reference mark: full counter-clockwise position - align mark on shaft to mark on face for start of measurement range



DIMENSIONS ARE IN INCHES [MM] tolerances are ± 0.02 in. [± 0.5 mm] unless otherwise noted

Ordering Information

Model Number:

order code:

Sample Model Number:

RT8DN - 100 - AL - 25 - FL - 500 - TR - SC5

(3) range: enclosure:

shaft:

100 turns powder-painted aluminum

.25-in diameter @ mounting style: baud rate:

terminating resistor: electrical termination: flange 500 k bits/sec.

5-meter cordset with straight plug

Full Stroke Range:

order code:	R125		R25		R50		1	2		3		5		10	20
clockwise shaft rotations, min:	0.125	1	0.25	1.1	0.50	•	1	2	-	3	•	5		10	 20
accuracy (% of f.s.):	1.25%	į	1.25%		0.5%	•	0.5%	0.5%		0.2%		0.2%	-	0.15%	 0.15%
potentiometer cycle life*:	2.5×10^{6}	-	2.5×10^{6}	0.70	2.5×10^{6}		2.5×10^{6}	2.5×10^{6}		5 x 10 ⁵	1	5 x 10 ⁵		2.5×10^{5}	2.5×10^5


® order code:	30	40	50	80	100	140		180		200
clockwise shaft rotations, min:	30	40	50	80	100	140	- 1	180	:	200
accuracy (% of f.s.):	0.15%	0.15%	0.15%	0.15%	0.15%	0.15%	•	0.15%	:	0.15%
potentiometer cycle life*:	2.5×10^{5}	2.5 x 10 ⁵	2.5×10^{5}	2.5 x 10 ⁵	2.5 x 10 ⁵	2.5 x 10 ⁵		2.5×10^{5}		2.5 x 10 ⁵

*—number of times the sensor shaft can be cycled back and forth from beginning to end and back to the beginning before any measurable signal degradation may occur.


Enclosure Material:

ΑL SS ♠ order code: 303 stainless steel powder-painted aluminum

Shaft Diameter:



Mounting Style:




Baud Rate:



Terminating Resistor:



Electrical Connection:



I/O Format

Not Used Not Used Not Used Full Stroke Range** Current Measurement Count* B₇ B₈ B₈ B₈ B₈ B₈ B₈ B₈ B₈ B₈ B₉ B₈ B₉ B₉ B₈ B₉ B₉

Data Field

*Current Measurement Count

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable.

The CMC is a 16-bit value that occupies the first two bytes (B_0 and B_1) of the data field. B_0 is the LSB (least significant byte) and B_1 is the MSB (most significant byte).

The CMC starts at 0000H with shaft at the full counter-clockwise position (0° reference mark) and continues in the clockwise direction to the end of the stroke range stopping at FFFFH. This holds true for all ranges.

**Full Stroke Range

The Full Stroke Range (FSR) is a 16-bit value in the data field that expresses the full range of the sensor in degrees. This value can be used to convert the actual count to units of measurement should the application require it.

B₁ = MSB current measurement byte

The full stroke measurement range occupies the second two bytes $(B_2 \text{ and } B_3)$ of the data field.

 B_2 is the LSB (least significant byte) and B_3 is the MSB (most significant byte).

This value is expressed in degrees.

Example:

Hex Value	Decimal Equivalent	Full Stroke Range
0168	360	360 degrees

Converting CMC to Degrees

B₃ = MSB full stroke range byte

If required, the CMC can easily be converted to a rotational measurement expressed in degrees instead of counts.

This is accomplished by first dividing the CMC by 65,535 (total counts over the range) and then multiplying that value by the FSR:

$$\left(\frac{\text{CMC}}{65,535}\right)$$
 X FSR

Example:

If the full stroke range is 1 turn (360 degrees) and the current position is OFF2 Hex (4082 Decimal)

$$\left(\frac{4082}{65,535}\right)$$
 X 360 deg. = 22.4 degrees

Address Setting (Node ID), Baud Rate and Bus Termination Settings

Address Setting (Node ID)

The Address Setting (Node ID) is set via 6 switches located on the 8-pole DIP switch found on the DeviceNET controller board located inside the transducer.

The DIP switch settings are binary starting with switch number $1 (= 2^0)$ and ending with switch number $6 (= 2^5)$.

	(2^{1})	(2^{2})	(2^3)	(24)	(2 ⁵)	(decimal)
0	0	0	0	0	0	0
1	0	0	0	0	0	1
0	1	0	0	0	0	2
			•••	•••		•••
1	1	1	1	1	1	63

Baud Rate

The transmission baud rate may be either factory preset at the time of order or set manually at the time of installation.


The baud rate can be set using switches 7 & 8 on the 8-pole DIP switch found on the DeviceNET controller board located inside the transducer.

DIP-7	DIP-8	baud rate					
		4051					
0	0	125k					
1	0	250k					
0	1	500k					
1	1	125k					
123456	78 🛊 = "1	."					


Bus Termination

The setting of the internal bus termination resistor may be specified upon order or manually changed by the end user at the time of installation.


The bus termination resistor is activated setting switches 1 & 2 on the 2-pole DIP switch (located on the internal DeviceNET controller board) to the "ON" position.



DeviceNET Controller Board and DIP Switch Location



to gain access to the controller board, remove four Allen-Head Screws and separate case halves



CLICK HERE > CONNECT WITH A SPECIALIST

NORTH AMERICA

Tel +1 800 522 6752

EUROPE

Tel +31 73 624 6999

ASIA

Tel +86 0400 820 6015

te.com/sensors

TE Connectivity, TE, TE Connectivity (logo) and Every Connection Counts are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's tandard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2021 TE Connectivity Corporation. All Rights Reserved.

Version # 02/2021